

GETTING LOST IN CANADA

# How To



Step-by-step instructions

# Table of Contents

|                                                       |   |
|-------------------------------------------------------|---|
| How To: Awning                                        | 3 |
| How To: Climate Control                               | 4 |
| How to: Empty water tanks                             | 5 |
| How to: Empty water tanks — At the station            | 6 |
| How to: Empty water tanks — Hooking at the campground | 7 |
| How to: Power management                              | 8 |
| How To: Water                                         | 9 |

# How To: Awning

## Extend

The awning is fully automated, easy stuff. The hardest part is finding the location of the awning control panel, next to the Garmin unit. The awning is located on the right side of the Garmin panel.

■ You should always keep an eye on the awning during operation.

## To extend

1. Look at the Awning control panel, located just to the right of the Garmin panel
2. Make sure the left toggle is set to ON
3. Press (no need to hold) extend on the right switch
4. The awning will now extend
5. When done, you may set the left toggle to off

## Retract

1. Look at the Awning control panel, located just to the right of the Garmin panel
2. Make sure the left toggle is set to ON
3. Press (no need to hold) retract on the right switch
4. The awning will now retract
5. When done, you may set the left toggle to off

# How To: Climate Control

## One time (mostly)

You will be working on the Truma control (set to external control) — see Truma panel, far left .

1. Select tools (the wrench icon)
2. Select

## Day-to-day operation

1. On the Garmin, right-hand side, select home
2. Click on the gear next words "Temperature control"
3. Click on auto
4. Adjust to the desired temperature
5. If there is no 120 VAC, and you need AC, the Truma panel will display "W 45 H", indicating AC is disabled.

# How to: Empty water tanks

## Getting ready

- ☐ Have on hand
  - ☐ The sewer hose & fittings
  - ☐ A fresh-water hose
  - ☐ Disposable gloves
  - ☐ Hand sanitizer
- ☐ Drive to the dump station and position the van so the sewer outlet lines up with the station's drain.
- ☐ Set the parking brake.

# How to: Empty water tanks

## At the station

### At the station

- ☐ Remove the sewer cap from the outlet.
- ☐ Connect the sewer hose: one end to the van's outlet, the other secured into the dump station drain.
- ☐ Open the black water valve first and let it fully drain. Draining black first keeps the worst waste moving through the hose while it's cleanest.
- ☐ Close the black water valve once it stops flowing.
- ☐ Open the gray water valve and let it fully drain — the gray water rinses out residual solids left behind by the black tank.
- ☐ Close the gray water valve.
- ☐ Flush the black tank using the factory flush port: connect a fresh-water hose to the port, open the black valve again, and run water until it runs clear, then close the valve.
- ☐ Rinse the sewer hose with a dump station rinse hose (or your fresh-water hose) while it's still connected, to flush out residue.
- ☐ Disconnect the hose starting from the tank end, letting any residual liquid drain into the dump station opening.
- ☐ Rinse the outlet cap and hose fittings, then recap the sewer outlet.

# How to: Empty water tanks

## Hooking at the campground

### Hooking at the campground

1. Under construction
2. Under construction

# How to: Power management

## Managing power

Every system you use in the van needs power. And, Unlike at your home, power is limited and must be managed. Some systems provide you with the power, some use said power. The trick is to match the two.



# How To: Water

## How to

1. First step using placeholder
2. Second step placeholder
3. Third step placeholder